

Operation manual

PinMark



UMC box



ÖSTLING
Markiersysteme GmbH

Broßhauser Str. 27
42697 Solingen - Deutschland

Tel.: +49 (0) 212 - 26 96 0
Fax.: +49 (0) 212 - 26 96 199

www.ostling.com



DIN EN ISO 9001:2000
Zertifikat: 01 100 060010

Edition: 04/2006

ÖSTLING Markiersysteme GmbH is not responsible for any errors in this documentation. A liability for indirect and direct damage, which develops in connection with the supply or the use of this documentation, is impossible, as far as this is legally permissible.

Table of contents

Chapter 1

Safety

1	For your safety	1-2
2	Definitions.....	1-2
3	Operational safety.....	1-3
3.1	Intended use of the marking system	1-3
3.2	Measures taken by the user/operator	1-4
	Consider warning plates and references.....	1-4
	Personnel instruction.....	1-4
	Duty to care in handling the marking system	1-5
	Use of intended spare parts and operational funds	1-5
3.3	Measures of the manufacturer	1-6
4	Danger overview.....	1-7

Chapter 2	Set-up	
1	Installation and Set-up of the Marking System	2-2
1.1	Installing the software	2-3
1.2	Built-in units.....	2-4
2	Measures to prevent electronic interference	2-5
2.1	Complying with interference suppression as per CE	2-6

Chapter 3	Description
1	Short description..... 3-2
2	Technical data 3-2
2.1	Marking units 3-2
2.2	Control UMC box..... 3-3
2.3	Software 3-3

Chapter 5 Maintenance

Chapter 6 Connector pin lists

0-5

Safety

B PM UMCbox en01.doc

1 For your safety

The UMC box coining unit has been developed as the newest, state-of-the-art marking system concerning safety and reliability.

We confirm that the UMC box marking system meets the fundamental safety and health requirements of the EEC machine guideline 98/37/EG. We provide the "EEC conformity explanation", and the CE-indication on the marking system.

The type plate is together with the CE-indication on the back of the UMC box.

We, as manufacturers of the marking system, want to make you, as operators, completely familiar with the UMC box marking system. An extensive chapter has been devoted to all the safety concepts of the marking system, and refers to possible dangers and measures to take.

Note

Consideration must be taken into account that generally accepted safety rules, and rules for the prevention of accidents goes beyond these references.

2 Definitions

Danger area ... is the range in the periphery of the marking system, in which safety or the health of a person is endangered by the stay in this range.

User ... is the person, in whose working area the marking system is set up and operated.

Operator/ Personnel ... are the persons, who are responsible for transport, list, start-up, enterprise, maintenance including cleaning and repair of the marking system.

3.1 Intended use of the marking system

From this marking system, however, dangers can proceed if it is used by untrained personnel inappropriately, or to not intended use. This can result in:

- Dangers for the safety of the operator.
- Impairment of the marking system and further real values of the user.
- Impairment of the efficient work of the marking system.

3.1 Intended use of the marking system

Intended use means in addition:

- The setting up conditions prescribed by the manufacturer must be kept and maintenance work must be accomplished.
- The installation of the marking system and its operation must stand in conformity with the valid national regulations of the user country. For their observance the user is responsible.

- Arbitrary changing or changes of the marking system by the user or operator.

- Each function, which could impair safety.

We assume no liability from not intended use!

Each use going beyond that is not considered as intended. For material damage and personal injuries resulting from this, the manufacturer is not responsible; the risk for this carries alone to the user.

3.2 Measures taken by the user/operator

Consider warning plates and references

Within operation and handling of the marking system, dangers can arise if not handled with proper care. In this manual, operating instructions are given, including appropriate warning references in the front. In addition, warning plates can be found on the marking system.

Note

Mind the warning references!

Mind the commands and interdictions of the warning references. They serve for your protection.

These warning references include:

- A symbol.
- References to the source and the kind of the danger.
- Instructions, how you can avoid the danger.

Example:



Heavy soiling impairs the marking system!

Marking system does not work efficiently any more.

- With heavily soiled ambient air use bellows (option) as cover.
- Maintain marking system regularly.

Personnel instruction

The marking system may be served, waited and repaired only by authorized, trained and instructed personnel.

Work on the electrical and pneumatic equipment may be implemented only by specially trained specialists.

In addition, the following measures must be taken before the personnel begins the work of using the marking system:

- Instructs over arising dangers.
- The user must obligate, to the extent necessary, the personnel for carrying protective clothing and gloves.
- Competencies for operation, maintenance and repair must be clearly specified, so that under the aspect of safety no unclear authority arises.
- Read the technical documentation of the marking system. It is recommended to the user to be confirmed in writing in each case that the personnel has read and understood the technical documentation.

Duty to care in handling the marking system

Guarantee perfect condition of the installation:

- The user and/or the circle of acquaintances assigned by him may operate the marking system exclusively in the perfect condition.
- The user must ensure cleanliness and clarity of the work place at the marking system by appropriate instructions and controls.
- The user must provide for sufficient circulation of fresh air in the work spaces.
- The operator must announce occurring changes (including the operational behaviour) of the marking system which impair safety, immediately to the user. In addition, the marking system must be examined at least once per shift for outwardly recognizable lack and damage.

With all work that concern transport, installation, start-up, operation, maintenance and repair, the prescribed switching-off procedures must be kept:

- With any adjustments, maintenance or repairs, the marking system must always be switched off over the MAIN SWITCH. Exceptions to it, with which the marking system must remain switched on with appropriate work, are noted in the manual in each case.
- With work on pneumatics:
 - Turn off and lock the compressed air supply.
 - Wait at least 5 s after turning off the compressed air supply, until the pressure diminishes itself.
 - Examine whether the operating pressure dropped on 0 bar. Read off the current operating pressure from the appropriate manometer.

Use of intended spare parts and operational funds

Original parts and accessories are particularly designed and manufactured for the marking system. Spare parts to use as original parts and accessories, which are not supplied by the manufacturer of the marking system, are not examined and approved by the manufacturer. The installation and/or the use of such products can possibly change the constructionally given characteristics of the marking system and endanger safety.

Note

For damage which results from the use of non-original parts and accessories and/or inadequate installation or exchange of original parts and accessories, the manufacturer assumes absolutely no liability or responsibility.

4 Danger overview


The following chart outlines potential hazardous risks and endangerment to one's life from the marking system. Through construction and design, as well as implementation of safety devices as defined by the EEC machine guideline 98/37/EG, will prevent dangers and promote safety to personnel. If the user of the marking system can provide additional measures for the prevention of dangers, the user finds these additional measures in the following chart.

Type of endangerment	Spot of endangerment	Danger	Additional measure
Mechanical endangerment • By squeezing	<ul style="list-style-type: none"> Marking tool Marking head 	Risk of injury Risk of injury	Do not reach into the danger area.
• By cutting and chopping off	<ul style="list-style-type: none"> Marking tool Marking head 	Risk of injury Risk of injury	Do not reach into the danger area.
Electrical endangerment • By electrical contact	<ul style="list-style-type: none"> Directly with parts that are normally under voltage. Indirectly with parts that are under voltage in failure. 	Danger of life Danger of life	- -
Endangerment caused by breakdown or failure • Failure in power supply	<ul style="list-style-type: none"> Drives Control voltage 	Risk of injury Risk of injury	- -

Tab. 1


1 Installation and Set-up of the Marking System

1. Install the marking system in compliance with all safety rules.
2. Supply the marking head with oiled and cleaned compressed air via the designated connection.



Connection cable for marking head and marking head

Fig. 10372



Back side of the control UMC box

Fig. 10388

3. Tuck the 21-pin plug of the connection cable (2) into the 21-pin connection (3) at the marking head. Ensure the coding pin of the plug is inserted into the flute of the connection.
4. To screw the plug: turn the outer ring of the plug clockwise.
5. Fix the grounding wire of the connection cable under a screw of the housing of the marking head.

- ## 1.1 Installing the software

- or**

1.2 Built-in units




Fig. 10262

All marking heads are supplied ready for use. The following points must be considered when installing the marking head into a production line:

- Built-in units must be installed adjustable to allow subsequent aligning and/or exact adjusting of the distance tool tip - workpiece.
- Use a bellows (option) as cover if the unit is operated in a heavily soiled working environment. This cover can be used only with horizontal installation of the unit.



Fig. 10276

- Marking tool can move down by itself, since the driving motors are dead after switching off the marking equipment and possess no automatic locking.
- Bellows (option) cannot be used.
- The y
- Y-axis is the axis with the shorter traverse path. The marking head may be inserted only with perpendicular Y-axis (see Fig. 10262, page 2-4).

2 Measures to prevent electronic interference

The following general references secure a trouble-free operation of an electrical system:

- Take the main power supply directly from the switch cabinet feed.
- Signal cables must not be laid together with cables carrying power.
- Signal cables may not be laid with cables from units that would cause interference (e. g. contactors, power motors). Otherwise use shielded mains cable and ground the shielding at one end. The same applies for the auxiliary power supply for controllers and isolating amplifiers.
- Sources of severe interference such as contactors and motors should be suppressed with RC components. Within the switch units only use switching equipment and other devices that have been suppressed by RC combinations, for example. It is necessary to note the standard codes of practice for electrical work (VDE, DIN and the corresponding EN).
- The reference value output must be shielded. The shielding must be grounded at one end.
- Controllers and switchover relays for the manual setting of reference values should be placed as close as possible to the program encoder. If it is not possible to do this, an isolating amplifier is to be installed in the reference value output immediately behind the program encoder.

2.1 Complying with interference suppression as per CE

The marking system UMC box, coining unit, is designed and build according to the regulations of the electromagnetic compatibility guideline. To ensure interference suppression the following points must be considered:

- Use shielded control cables to connect all external components (e. g. marking head, foot switch, signal inputs and outputs) to the connection BU2 (DB37) at the control. At the back of the control the shielding of all the cables must be connected at the controller end to the grounding screw (11, Fig. 10388, page 2-2) via a cable that must be kept as short as possible.
- The grounding screw of the control UMC box must be connected to the system ground (at the power supply feed) via a separate grounding cable. When integrating the control into a more sophisticated production line the grounding screw must be connected with the central ground supply point of the line via a separate grounding cable. The cross-section of the cable should be at least 2.5 mm².
- Length connection cable control - marking head max. 2 m.
- Cable foot switch two-core with shielding, a two-pole jack plug made of plastic must be used.
- Length cable foot switch max. 3 m.
- Lay the connection cable control - marking head and the cable foot switch separately from any possible sources of interference (see also paragraph 2).
- The following should be noted when connecting external components to the control UMC box:
 - The components used (e. g. monitor, printer) must likewise comply with the CE standards for industrial use.
 - Length connection cable control - external component max. 2 m. Shielded cables and plugs with metal housings must be used.
 - If connections to or from the serial port (RS232) cause functional errors, change over from this type of connection to one that is not subject to interference (e. g. RS485, fiber optic connection, galvanic separation through an opto-electronic coupler).

Description

B PM UMCbox en03.doc

1 Short description

The UMC box, coining unit, is a marking system for marking products through coining.

Coining When coining, the marking takes place via a carbide point, which is brought to oscillating by compressed air. The carbide point is moved in X- and Y-direction by a coordinate unit with two stepping motors. Thus, material in the workpiece is compressed and/or displaced. In continuous operation the marking consists of a dense sequence of individual points which results in a closed line.

Engraving units cannot be operated with the UMC box.

2 Technical data

2.1 Marking units

Resolution	[mm]	standard 0.1
Coining frequency	[Hz]	oscillating freely approx. 200 or controlled 20 - 150
Marking speed	[characters/s]	1 - 5
Compressed air	[bar]	max. 6
Electricity, voltage	[V]	115 or 230
net frequency	[Hz]	60 or 50

Tab. 1

2.2 Control UMC box

Computer	external PC	
System requirements computer	Intel Pentium or equivalent with Microsoft Windows 2000 or XP	
	clock frequency [GHz]	1
	RAM [MB]	512
	hard disc space [MB]	20
	colour monitor [Pixel]	min. 1024 x 768, 65K colours
	CD drive	
Ports	COM (RS232, RS485)	
Memory	on external PC	
Motor drive	ÖSTLING 2 axis motor electronics, max. phase current 2 A	
Outputs	24 V, max. 0.5 A, ready for operation, ready to mark, marking	
Inputs	17 - 30 V DC, start with foot switch, E-STOP	
Display	4 status LED	
Keyboard	compact integrated keypad with 2 keys	
Dimensions	width [mm]	310
	depth [mm]	176
	height [mm]	75
Weight	[kg]	approx. 2.5
Electricity	24 V DC via external power supply, 90 - 250 V 50/60 Hz, max. 50 W	
Temperature range	0 °C - 45 °C, non condensing	

Tab. 2

2.3 Software

Mask	max. 31 text fields with up to 50 characters each or one graphic	
Font	15 fonts (see chapter 4)	
Character height	[mm]	0.5 - 99.9
Character width	width factor	0.1 - 10
Character spacing	[mm]	0 - 10
Character direction	horizontal, vertical, at any angle on any arc, clockwise or anti-clockwise	
Special characters	import of HPGL plotting files (*.plt)	
Additional functions	counter, date and time, query of text (also with bar code reader) before each marking, shift index	

Tab. 3

Fig. 10389

- ## Marking heads

All marking head compatible with the UMC box are equipped with a toothed belt drive. All marking heads have 2 linear axes.

- During high marking speed the quality of the marking result does not only diminish, but also step error arises by the mass inertia of the marking head. The maximum marking speed depends therefore on the assigned marking head and its maintenance. Bad maintenance decreases the maximum marking speed (for maintenance see chapter 5).

Marking speeds over 80 mm/s produce nearly always insufficient marking results. In addition it can occur in very rare cases that the resonant frequency of the stepping motors is reached. In the case of resonance a strong decrease of torsional moment takes place. In this case a slightly (1 - 2 mm/s) higher or lower marking speed must be selected.

Marking speeds that are inherently dangerous to the marking head or other parts of the marking systems will generate an error.

Combination unit with marking head

Not every marking head is available in every unit design:

Designation marking head	Size of the marking field [mm]	Table unit	Hand-held unit	Built-in unit	Combination unit
MagicPin	30 x 50	-	+	-	-
3 / 5	30 x 50	+	+	+	+
4 / 6	40 x 60	-	-	+	-
5 / 9	50 x 90	+	+	+	+
8 / 14	80 x 140	+	+	+	+

+: available
-: not available

Tab. 4





3.2 Marking tools

The carbide point of the marking tool is brought to oscillating by compressed air. The marking image (text, graphic) is coined into the workpiece as a dense sequence of individual points. Thus material in the workpiece is displaced.

Examples for marking tools

Note

Not all marking tools can be used in each marking head. There are different sizes of tool fittings.

Coining tool WE 2 Art.-Nr. 45.22.0000	Coining tool WE 3 Art.-Nr. 45.30.0000
	<ul style="list-style-type: none"> • blue housing <p>The needle tip is brought to independent swinging by compressed air. The frequency amounts to approx. 200 Hz (depending on the pressure and work distance x). Thus material in the workpiece is compressed and/or displaced.</p> <p>This coining tool is characterised by a high needle frequency and is therefore suitable for nearly all applications. Even the smallest markings are producible trouble-free.</p>
	<p>Application:</p> <ul style="list-style-type: none"> • applicable in the coining heads 4 / 6, 5 / 9 and 8 / 14. • work distance x = 1 - 3 mm. • working pressure: 3 - 6 bar.
	<ul style="list-style-type: none"> • red housing <p>The needle tip is brought to independent swinging by compressed air. The frequency amounts to approx. 200 Hz (depending on the pressure and work distance x). Thus material in the workpiece is compressed and/or displaced.</p> <p>This coining tool is characterised by a high needle frequency and is therefore suitable for nearly all applications. Even the smallest markings are producible trouble-free.</p>
	<p>Application:</p> <ul style="list-style-type: none"> • applicable in the coining heads 3 / 5 and MagicPin. • work distance x = 1 - 3 mm. • working pressure: 3 - 6 bar.

Tab. 5

Tab. 6

3.3 Control UMC box

All coining heads of the PinMark family can be controlled by the control UMC box.

The external PC (not included in delivery) communicates with the control over the RS232 interface. In addition the control and thus the entire marking system can be controlled from external. For this purpose digital inputs and outputs are present.

Software The software PinWare offers true WYSIWYG ("what you see is what you get"): it shows an exact preview of the marking result on the workpiece.

Both writings and graphics (format * plt) can be imported by the software and marked thereby. The software contains by default several character sets including their special characters and umlauts. All characters can be aligned and arranged freely, the arrangement on a circular arc is likewise possible.


Wildcards or objects can be used in marking. E. g. the current date, time or serial number all of which increases automatically after each marking. Also variable data, which will be entered directly before the marking by the user, can be used. And all this without changing the marking sample each time.

For more information about the software see chapter 4.

4 External communication

The marking system can communicate with external controls via the connection BU2. Digital I/O signals are sent via this connection, e. g. start with foot switch, ready for operation, ready to mark, marking and E-STOP.

The high level of the input signals is defined between 17 -30 V DC, the high level for output signals will be 24 V DC. The maximum current you can take from all output signal together is 0.5 A (see chapter 6).



Timing diagram signals on BU2

Fig. 10401en

ÖSTLING Markiersysteme GmbH

1.1 Pushbuttons

- Pushbutton ENTER for acknowledgment and start of the marking.
- Pushbutton ESC for program abort.

- 4 status LEDs.

1.1 Pushbuttons

The diagram shows the front panel of the UMC box. It features a black top section with a blue diagonal stripe on the right containing the 'OSLING' logo. Below this is a white horizontal band with the text 'UMC box'. The bottom section is black and contains six control elements, each with a numbered callout line pointing to it:

- 1: A green square button with a white right-pointing arrow.
- 2: A red square button with a white circle and a diagonal line through it.
- 3: A white rocker switch with a lightning bolt symbol on the left.
- 4: A green LED indicator with a small green dot above it.
- 5: An orange LED indicator with a small orange dot above it.
- 6: A blue LED indicator with a small blue dot above it.

Fig. 10392

The software is designed in such a way that from switching on the control up to the start of marking you can always press ENTER on the front of the control in order to confirm the next step.

1.2 Status-LEDs

4 coloured LEDs are situated at the front of the UMC box. They indicate the current status of the marking system.

After switching on the UMC box the LEDs are tested: all 4 LEDs are switched on and off again for 3 s one after the other. The white LED "Power on" remains switched on.

- | | |
|----------------------------------|---|
| LED "Power on" | The white LED (3, Fig. 10392, page 4-3) shines when the MAIN SWITCH of the control is switched on and 24 V DC are impressed to the control. |
| LED "Ready for operation" | <p>The green LED (4) indicates that the motor electronics is ready to move the axes of the marking head. The LED shines when the motor electronics is initialised.</p> <p>If no marking head is connected to the UMC box or the stepping motors of the marking head are defective, the green LED flashes.</p> |
| LED "Ready for marking" | If the yellow LED (5) shines, the marking system is ready for marking. When a mask is loaded in the software and <i>Marking > Start</i> is selected, it can be marked. The marking is started with ENTER, with the foot switch or over the input E1.0 of the connection BU2. |
| LED "Marking" | The blue LED (6) shines during the marking and during communication between CPU card and motor electronics. |

2.1 Text fields, Masks and Projects

If more than 31 text fields are needed for the marking of a workpiece, several masks must be created. If a text field shall contain more than 50 characters, its content must be divided on 2 text fields. However, only one mask can be loaded and marked.

Example A mask e. g. corresponds to a type plate, the text fields correspond to the individual fields of the type plate like year of manufacture, serial number, etc.

The arrangement of a text field within the mask is determined by the X- and Y-coordinates of the text field. The origin of the coordinate system lies in the lower left corner of the marking area.

Switching on the control



- Control boots, axes of the marking head reference: the slide of the marking head moves in X-direction until the X-initiator actuates. Then it continues to move in X-direction by the value of "Overtravel" (see page 4-29). The slide moves likewise in Y-direction. The reached position is defined as basing point of the marking head. This basing point is the origin of the marking field.

PinWare 4.3110

File Edit Marking System Help Menubar [F10]

F1-Load File

F2-Start

F3-Edit File

ÖSILING





DEMO

OSIMARK

File: default.msk
Edit Mode

Fig. 10393en

2.3 Brief instruction: marking a workpiece

1. Switch on control via MAIN SWITCH.
2. Select  *Load file*.
3. Select the desired file.
4. Select .
5. Enter the number of workpieces to be marked behind "Number".
6. Select  to start the marking. To mark another workpiece: select  again.

3.1 Creating a text field

Type text field 5 different types of text field are available:

- Alignment** Depending on the type of the text field different alignments are available. For the types "Text", "HPGL file" and "DataMatrix Symbol":


- The following alignments are available for the type "Circular text":

- ### Note

B PM UMCbox en04.doc

Creating a new text field

1. Select *File > New mask*.
"Mask Data" appears.



Mask "Mask Data"

Fig. 10221en

2. Enter the number of the text field behind "Textfield".
3. Select the desired type of text field (see page 4-8) behind "Type".
Depending on the selected "Type" a different number of further input fields are displayed.
4. Select the desired alignment of the text field (see page 4-8) under "Alignment".
5. Enter the X- and Y-position of the reference point (see Alignment on page 4-8) under "XPos" and "YPos".
6. Enter the marking speed under "V [mm/s]".

Note



Text field with $V = 0$ mm/s are not marked and are displayed in the preview in blue colour.

7. Enter the character height of the capital letters in [mm] under "Height". Heights from 0.5 to 99.9 mm can be entered. When marking a data matrix enter the "Dot size" in [mm].
8. If the characters of the text shall be marked wider or smaller than standard: enter a value unequal to 1.0 under "Widthfactor". Character widths from 0.1 to 10 can be entered.
0.5 causes half character width, 2.0 double character width.
9. If the spacing between 2 adjacent characters shall be larger than standard: enter a value between 0 and 10 in [mm] under "Spacing".

- or**

- or**

13. To select the "Font":

- Select  CHR.
- Select the desired font from the list (overview fonts see page 4-35).
- Select .

14. To see a preview of the text to be marked: select

Editing a text field


A text field that is already created can be edited in the edit or service mode at any time.

1. If the mask in which the text field shall be edited is not the current mask: select *File > Open mask* in the main menu.

or


- Select *Load file*.

"Load File" appears.



Mask "Load File"

Fig. 10222en

2. Select the desired file (mask).
 3. Select .
 4. Select *Edit > Mask* in the main menu.
- or
- Select *Edit File*.
5. Enter the number of the text field to be edited behind "Textfield".
- or
- Select the desired text field with the arrow keys.
6. Edit the text field (see page 4-9).

3.2 Working with wildcards

Instead of text also a wildcard can be entered in a text field. With wildcards variable information (e. g. current date or time) can be marked. The information isn't queried by the system until the marking takes place.

Wildcards are included by 2 "@" characters. Several wildcards can be combined. The characters . - , : / and the blank can be used together with wildcards, in order to obtain e. g. usual formatting of dates.

The following wildcards are available:

Type of wildcard	Entry	Result	Example
Day	T	Day in the week	1, 2, 3, ..., 7
Day	TT	Day in the month (two-digits)	01, 02, 03, ..., 31
Day	ttt	Day in the year	1, 2, 3, ..., 366
Week	KW	Week (two-digits)	01, 02, 03, ..., 53
Month	MM	Number of the month (two-digit)	01, 02, 03, ..., 12
Year	J	Date (last digit)	0, 1, 2, ..., 9
Year	JJ	Date (last 2 digits)	98, 99, 00
Year	JJJJ	Date (four-digit)	2005
Time	hh	Hour (two-digit)	00, 01, 02, ..., 23
Time	mm	Minute (two-digit)	00, 01, 02, ..., 59
Time	ss	Second (two-digit)	00, 01, 02, ..., 59
Counter	arbitrary number	Number which is increased automatically.	100, 101, 102, ...

Tab. 1

Example:

Example:
A text field with the content: Date: @TT.MM.JJ@ Time: @hh:mm@
e. g. generates: Date: 19.01.05 Time: 09:26

3.3 Creating objects

In addition to wildcards, objects can also be entered in text fields. The following objects are available:

- Counter.
- Date and time.
- User input: text field is reserved for data that are entered by the user just before the marking. The query of the data occurs automatically.
- Shift index.


Note

If "Autosave" is selected under *System > Options*, the current counter value is saved in the object list, too.

Objects are activated with a "%" character. Several objects can be combined.

Creating a counter

1. Select *Edit > Object List*.
or
 - Select *OL* in "Mask Data"."Object List" appears.
2. Select unimplemented object or object "Counter" to be changed and select ENTER.
"Counter Object" appears.




Mask "Counter object"

Fig. 10223en

-


Creating the object "Date and Time"

1. Select *Edit > Object List*.
or
 - Select *OL* in "Mask Data"."Object List" appears.
2. Select unimplemented object or object "Counter" to be changed and select ENTER.
3. Select "Date and Time" in the field on the right.




Mask "Date and Time Object"

Fig. 10224en

4. Enter the value "Format": format of the date/time (see "Working with wildcards" page 4-12).
5. If desired, also special formats of the date can be marked: Enter the letters A B C (if desired with separators) and the values of A, B and C in the lower rows:
 - "Day Code-A": 31 digits or letters from which the digit and/or the letter is marked which corresponds to the current day.
 - "Month Code-B": 12 digits or letters from which the digit and/or the letter is marked which corresponds to the current month.
 - "Year Code-C": 10 digits or letters from which the digit and/or the letter is marked which corresponds to the current year.
6. To assume the object in the object list: select .

Creating the object "User Input"

1. Select *Edit > Object List*.
 or
 - Select OL in "Mask Data".
 "Object List" appears.
2. Select unimplemented object or object "Counter" to be changed and select ENTER.
3. Select "User Input" in the field on the right.



Mask "User Input"

Fig. 10225en

4. Enter the following values:
 - "Message": message that is displayed if the system waits for an input from the user, e. g. Fig. 10235. The message is only displayed if "Enable Prompt" is selected.



Fig. 10235en

-

Creating a shift index

- or**




Fig. 10226en

- 

3.4 Saving masks

1. Create the mask with all desired text fields (see paragraph 3.1, page 4-8).
2. Select *File > Save Mask*.


If a new mask is saved (mask doesn't have a file name yet) "Save File" appears.

If the mask has been saved once and therefore has a file name, the mask will be saved. The following steps are inapplicable.

or


- Select *File > Save Mask As.*

"Save File" appears.



Mask "Save File"

Fig. 10266en


3. Enter file name you wish to give to the mask.
The ending '.msk' is automatically added by the software.
4. Select .

4 Working with projects

If the same masks are used on different marking units with different marking heads, the masks can be stored as projects. Beside the mask with all text fields a project contains also all current adjustments e. g. used marking head. If the mask is stored as project, these adjustments must be entered only once for each marking head. If the mask is to be marked again with one of these marking heads, just open the corresponding project.


4.1 Saving a mask and adjustments as project

1. Create the mask with all desired text fields (see paragraph 3.1, page 4-8).
2. Enter all other adjustments, e. g. used marking tool (see paragraph 7.5, page 4-31).
3. Select *File > Save Project As*.
 "Save File" appears.




Mask "Save File"

Fig. 10267en

4. Enter file name you wish to give to the project.
 The ending '.prj' is automatically added by the software.
5. Select .


4.2 Opening a project

1. Select *File > Open Project*.
"Load File" appears.



Mask "Load File"

Fig. 10268en

2. Select the desired file (project).
3. Select .


Project is opened: mask which is stored in this project is opened, all stored adjustments are assumed by the control.


Note

The marking unit does **not** give a feedback to the control which marking head or which marking tool is attached to the marking unit. When working with projects the stored adjustments must be controlled by the user.

5 Marking a workpiece





5.1 Preview on marking

1. To see a preview of the mask to be marked: select *Marking > Preview*.
or
- Select  in "Mask Data".
"Preview" appears.



Mask "Preview"

Fig. 10269en

2. To scale up the view: select .
 3. To reset the view to normal view: select .
 4. To make still some changes in the mask: select  *Edit*.
 5. To control the marking movements of the marking tool without marking the workpiece: select .
- Marking head retraces the marking without movement of the marking tool.

5.2 Starting the marking

- "Print" appears.




Fig. 10270en


- After the marking, the system indicates behind "Time" how long the marking has lasted in [s].

6 Further functions

6.1 Importing data



Texts from files which are on an external storage medium (disk, net drive assembly) can be imported. The software assumes all characters from the file. These characters are inserted in one or more text fields of one or several masks.

1. Select *Edit > Data import*.
 "Mask Data Import" appears.



Mask "Mask Data Import"

Fig. 10272en

2. Select the desired "Import Path".
3. To open the directory in which the file with the data to be imported is saved:
 select  behind "Import File".
 "File Selection" appears.
4. Select the desired file.
5. Select .
 "File Selection" is closed.

-

6.2 Changing the mode

3 different modes are available at the control:

- Work mode: files (projects and masks) can be loaded and marked.
- Edit mode: files (projects and masks) can be loaded, changed and marked. It is also possible to create new masks and projects.
- Service mode: all operating functions are possible. E. g. also system parameters can be changed.

The mode of the control can be changed at any time. If the edit and/or service mode is protected with a password, (see page 4-34), the password must be entered.

-

Control is changed to the selected mode.

7.1 Reading out diagnostic data

- "Diagnostic" appears.



Fig. 10247en

- Pinware Version: software version that is installed on the control.
- Install Version: version of the compact flash card.
- Firmware Version: software version of the motor card.
- Ambient/Heat sink temperature: temperature of the ambient air in [°C] and temperature of the heat sink of the motor card in [°C].
- Machine status:
 - MS: system status, 5-digit. Contains information about temperatures, voltage ranges and output drivers.

Digit	Description	Status	Description of the status
left-most	Output driver	0	Error.
		1	OK.
2. from left	Supply voltage: voltage in [V] that impressed to the motor card.	0	No voltage.
		1	Voltage OK.
		2	High voltage.
		3	To high voltage, error.
		4	Low voltage.
		5	Too low voltage, error.


Tab. 2

- Tab. 3

- 4-27

7.2 Operating the marking head in manual operation

1. Select *System > Manual Control*.
"Manual Operation" appears.



Mask "Manual Operation"

Fig. 10240en

2. To move the marking tool manually: enter step width in [mm].
3. Select F6 to F9 to move the marking tool in the desired direction.
4. To operate the marking tool with HPGL commands: enter HPGL command and select *Send*.

Note

The motor card uses HPGL commands to control the marking head. The plotter language was created by Hewlett Packard to process vector data for plotters.


5. To move home the marking tool: select *Home*.
6. To move the marking tool up and down once: select *Needle*.

1. Select *System > Marking Head Parameters*.
"Markinghead Parameters" appears.
2. Select "MotorCard".



- Current: motor current in [mA].
- Boost: increase of the motor current in [mA] during ramping.
- MaxPos: maximum position in [mm] the marking head can reach. According to the marking field.
Example: 90 mm in X-direction, 50 mm in Y-direction for marking head 5/9.
- mm/step: with coining heads: feed in [mm] after each drop of the coining tool.
- Ramptime: time in [ms] during which the motor current is increased.
- MaxV: travel speed of the marking head in X- or Y-direction in [mm/s] during deadhead.
- HomeV: speed of the marking head in X- or Y-direction in [mm/s] during homing.
- Overtravel: position of the initiator. An initiator is an inductive proximity switch. Distance of the initiator from home in [mm] in X- or Y-direction.


"Markinghead Origin" appears.



- ÖSTLING Markiersysteme GmbH


7.5 Selecting the marking tool

1. Select *System > Needle Parameters*.
"Needle Parameters" appears.



Mask "Needle Parameters"


Fig. 10250en

2. Select the desired marking tool behind "Needle Type".
Image of the selected marking tool is displayed.
3. If desired, change the parameters of the marking tool:
 - Turn-on delay: The needle of the marking tool is brought to oscillating by compressed air. Due to the mass inertia of the needle the oscillation achieves the entire amplitude only after short time. Then the marking tool is moved. This time in [ms] is the turn-on delay.
 - Turn-off delay: After switching off the compressed air the needle continues to swing still a short time due to the mass inertia. Only after this time (= turn-off delay) in [ms] the marking tool may be proceeded to the starting point of the next marking.
 - Frequency (only with WP needles): frequency in [Hz] with which the needle is brought to oscillating.
 - Needle on time (only with WP needles): time in [ms] during which the needle is brought to oscillating.
4. To test the marking tool: select  and hold the button.

Selecting the language


-
- The screenshot shows a Windows-style dialog box titled "Options". The title bar includes the "Pinware" logo and standard minimize, maximize, and close buttons. The main content area has a dark blue background with the word "Options" in white. Below this, there is a "Language" section. The word "Language" is enclosed in a dashed rectangular box. To its right are two buttons: "Pinware" and "Mode". Further down, the text "Select Language:" is followed by a dropdown menu that currently displays "English". At the bottom of the dialog, there are two buttons: "OK" with a green arrow icon and "Cancel" with a red square icon.

Fig. 10394en

2. Select the desired language.
3. To convert the software into the selected language: select 


Selecting software adjustments

1. Select *System > Options*.
"Options" appears.
2. Select "Pinware".




Mask "Options", Tab "Pinware"

Fig. 10395en

- Autostart: If selected the page "Print" appears directly when booting the control.
- Autosave: If selected the current mask is saved after each marking. Use this function if e. g. the current value of a counter is to be saved.
- Auto-Data Refresh: If selected changeable data (e. g. time, date) refreshed at once.
- Tooltip: If selected tooltips are displayed (short explanations to the field on which the mouse is).
- Number of marking: default how often a mask is marked. This value is displayed on "Print" behind "Number" (see Fig. 10270, page 4-23). The value "-1" corresponds to endless markings, the field "Number" will not be displayed.
E. g. if generally at least 10 markings are needed of all masks, "10" can be entered here, so that before each start of a marking the number doesn't have to be set manually to 10.
- Default font: font used by default when creating a mask. Select  to change the font.

Changing the start mode of the control

1. Select *System > Options*.
"Options" appears.
2. Select "Mode".



Mask "Options", Tab "Mode"

Fig. 10396en


3. Select the desired start mode:
 - Work mode: files (projects and masks) can be loaded and marked.
 - Edit mode: files (projects and masks) can be loaded, changed and marked. It is also possible to create new masks and projects.
 - Service mode: all operating functions are possible. E. g. also system parameters can be changed.
4. If the edit mode is to be made accessible only for a certain person subgroup and therefore is to be protected with a password: enter password.
5. If the service mode is to be made accessible only for a certain person subgroup and therefore is to be protected with a password: enter password.

Note

Passwords cannot be read out anywhere! Therefore if possible select a password which cannot be forgotten.

6. Select .

8 Fonts

15 different fonts are available in the software. By default the software uses the font 'litt.chr'. To select another font: select  CHR in "Mask Data" and select the desired font from the list (see page 4-10).

For every individual of the 31 text fields of a mask you can select another font. As a result of the different layouts of the individual fonts however differences can arise in the character width, height and size.

8.1 Default font

By default the software uses the font 'litt.chr' if no other font was selected.



Default font 'litt.chr'

Fig. 10283

The 'litt.chr' consists of 96 characters. It contains the moving lines with the corresponding positions of the marking tools for all 96 characters. In addition each character contains the character height and broad of the grid. This is not the actually marked character height and broad, but the vertical and horizontal resolution of the character.

The default font has a vertical resolution of 7 steps. That is a letter is defined by a resolution of 7 steps, based on capital letters. Umlaut in capitalisation and special characters exceed the normal character height, lower case with descender such as g, p, q, y and special characters fall below the character height of 0.

A coordinate plane with x and y axes ranging from -2 to 8. The x-axis is labeled with 0, 2, 4, 5. The y-axis is labeled with -2, 0, 5, 7, 8. A polygon is plotted with vertices at (0, 5.5), (1, 7), (4, 7), (4, 5.5), (4, 0), (1, 0), and (0, 0.5). A V-shaped graph is plotted with vertices at (1, -2), (2, 0), and (5, 5). Two points are marked on the y-axis at (0, 8) and (5, 8).


Fig. 10293

8.2 Further fonts

- bold.chr
- d5x7.chr: dot font.
- euro.chr
- goth.chr
- lcom.chr
- ocrA.chr
- rlit.chr: cyrillic font.
- rtri.chr: cyrillic font.
- sans.chr
- scri.chr
- sima.chr
- simp.chr
- trip.chr
- tscr.chr



Font 'bold.chr' Fig. 10277



Font 'd5x7.chr' Fig. 10278



Font 'euro.chr' Fig. 10280



Font 'goth.chr' Fig. 10281

Fig. 10282

Fig. 10284

Fig. 10285

Fig. 10286



Font 'sans.chr'

Fig. 10287



Font 'scri.chr'

Fig. 10288



Font 'sima.chr'

Fig. 10289



Font 'simp.chr'

Fig. 10290

Fig. 10291

Fig. 10292

Maintenance

B PM UMCbox en05.doc

1 General Guidelines for maintenance

Note

Unprofessional usage of controls or marking head voids the warranty.

General guidelines for maintenance:

- With all adjustments, maintenance and repair works, the control must always be switched off and the marking unit must be separated from the power supply. For that purpose, pull the power supply plug before opening the unit. Exceptions of it, with which the unit must remain switched on during appropriate work, are noted in the maintenance instructions in each case.
- With work on pneumatics:
 - Turn off and lock the compressed air supply.
 - Wait at least 5 s after turning off the compressed air supply, until the pressure diminishes itself.
 - Examine whether the operating pressure dropped on 0 bar. Read off the current operating pressure from the appropriate manometer.

1.1 Maintenance overview

Operating hours	Maintenance place	Maintenance work	Page
40	Slides of the axes	Check the slides on smooth running	5-8
2000	Exhaust air silencer	Clean the silencer, change it if necessary	5-5
If necessary	Toothed belts of the axes	Check the toothed belts on wear Check the tension of the toothed belts	5-6
If necessary	Toothed belts of the axes	Change the toothed belts	5-7
If necessary	Pneumatic maintenance unit	Adjust the oiler	5-10

Tab. 1

For single-shift operation:

Operating hours	Maintenance interval
40	Weekly
500	Every 3 month
2000	Annually

Tab. 2

1.2 Lubricants


Note

You can use also another lubricant, if this has verifiably the same characteristics. For example, the lubricant recommended here.

Maintenance place	Lubricant	ÖSTLING Art. number	Viscosity	Classification according to DIN 51825
Slides of the axes	SF06	-	Class 0	KOG-20
Pneumatic maintenance unit with oiler	Drawlub 28	45100111	k. A.	k. A.

Tab. 3


2.1 Maintenance overview



Exhaust air silencer

**Clean the
silencer** Every 2000 operating hours.

- 1 Silencer



Marking head from the bottom

3. Unscrew the silencer, wash it with warm water (max. 40 °C) and reassemble it.
4. If the silencer is very dirty: assemble a new silencer.


Toothed belts of the axes

(see page 5-4)

Check the toothed belts

If necessary, i. e. if the slides (see page 5-8) are tight or with loss of quality of the marking.

1. Switch off the control and pull the power supply plug.
2. Unscrew the covering cap of the marking head.



Marking head without covering cap

Fig. 10195

3. Check the tension of the toothed belt.
Toothed belt must sit tensely.

Note

Sometimes the toothed belt of the Y-axis is better accessible from down than from above. For that purpose turn the marking head upside down.

4. Check the toothed belt of the X- and Y-axis on wear.
If the tension of the toothed belt is too low or a toothed belt is worn out, this toothed belt must be changed (see page 5-7).
5. Reassemble the covering cap of the marking head.

Change a toothed belt	If necessary, i. e. if the tension of the toothed belt is too low or a toothed belt is worn out.
------------------------------	--

1. Switch off the control and pull the power supply plug.
2. Unscrew the covering cap of the marking head.
3. Loosen the eccentric screw for toothed belt (2 or 4).
4. Loosen the fastening toothed belt (for X-axis: 3).
5. Remove old toothed belt.
6. Mount new toothed belt.
7. Fix the toothed belt with fastening toothed belt (for X-axis: 3).
8. Tighten the eccentric screw (2 or 4).
Toothed belt must sit tensely.
9. Reassemble the covering cap of the marking head.


Slides of the axes

(see page 5-4)

**Check on
smooth running**

Every 40 operating hours.

1. Switch off the control.
2. Move the slides manually in X- and Y-direction.
Slides must be movable easily by hand.
3. If the slides can be moved only with difficulty: lubricate the guiding rods of the axes:



Marking head without covering cap

Fig. 10191

3.2 Maintenance instruction

Pneumatic maintenance unit

Note

2 different maintenance units are used at the PinMark marking units.

Use	Type of maintenance unit	FESTO type
All marking tools	Filter control valve with pressure reducer	Festo LFR 1/8 D-Mini
Marking tools WE 1 and/or WE 4 with hardened steel piston housing	Filter control valve with pressure reducer and oiler	Festo FRC 1/8 D-Mini, consisting of: <ul style="list-style-type: none"> • LFR 1/8 D-Mini. • LOE 1/8 D-Mini.

Tab. 4

For maintenance of the pneumatic parts please observe the operation manual of FESTO.

Set the oiler If necessary.

1. Do not switch off the control!
2. To switch on the marking tool in manual operation: select *System > Manual Control*.





Fig. 10240en

3. Select *Needle* to move the marking tool up and down once.
4. Adjust the oiler to approx. 1 drop per minute, see operation manual of FESTO.

Connector pin lists

1	Marking head	6-2
1.1	Plug to UMC box	6-2
1.2	Stepping motors	6-3
	Colour coding	6-3
	Circuit	6-3
2	Control UMC box	6-4
2.1	Socket BU1 to marking head	6-5
2.2	Socket BU2	6-6
2.3	Serial port START	6-7
3	Connection cable for marking head	6-8

1.1 Plug to UMC box



Pin		Axis	Colour of the cable	Name	Remark
1	A	X	pink	motor X-axis: phase 2A	
2	B	X	black	motor X-axis: phase 1A	
3	C	X	blue	motor X-axis: phase 2B	
4	D	X	green	motor X-axis: phase 1B	
5	E	Y	pink	motor Y-axis: phase 2A	
6	F	Y	black	motor Y-axis: phase 1A	
7	G	Y	blue	motor Y-axis: phase 2B	
8	H	Y	green	motor Y-axis: phase 1B	
9	I			reserved	
10	K			reserved	
11	L			reserved	
12	M		black	foot switch - E1.0	option
13	N	X	black	initiator output X - E1.1	
14	P	Y	black	initiator output Y - E1.2	
15	R		black	output needle valve - A1.0	
16	S	X	brown	+24 V - initiator X	
17	T	Y	brown	+24 V - initiator Y	
18	U		brown	+24 V - foot switch	option
19	V	X	blue	0 V - initiator X	
20	W	Y	blue	0 V - initiator Y	
21	X		black	0 V - needle valve	

Tab. 1

Colour coding

Tab. 2

Circuit





Fig. 10377en


2 Control UMC box



Back side of the control UMC box

Fig. 10388

2.1 Socket BU1 to marking head



The plug BU1 for the connection of the marking head to the control has 26 pins.

Pin	Name	Remark
1	motor X-axis: phase 2A	
2	motor X-axis: phase 1A	
3	motor X-axis: phase 2B	
4	motor X-axis: phase 1B	
5	motor Y-axis: phase 2A	
6	motor Y-axis: phase 1A	
7	motor Y-axis: phase 2B	
8	motor Y-axis: phase 1B	
9	reserved	
10	reserved	
11	reserved	
12	foot switch start E1.0	digital input
13	initiator X	digital input
14	initiator Y	digital input
15	output needle valve - A1.0	output (is wired with +24 V DC internally)
16	+24 V DC intern	output (internal voltage)
17	+24 V DC intern	output (internal voltage)
18	+24 V DC intern	output (internal voltage)
19	GND	0V DC
20	GND	0V DC
21	GND	0V DC
22	reserved	
23	reserved	
24	reserved	
25	reserved	
26	reserved	

Tab. 3

Phase	Colour of the cable	Phase	Colour of the cable
Phase 1A	black	Phase 2A	red
Phase 1B	orange	Phase 2B	yellow
Jumper 1	black - white/ orange -white	Jumper 2	red - white/ yellow - white

Tab. 4

The high level of the input signals is defined between 17 -30 V DC, the high level for output signals will be 24 V DC. The maximum current you can take from all output signal together is 0.5 A.

B PM UMCbox en06.doc

Tab. 5

Tab. 6

3 Connection cable for marking head

Pin		Colour of the cable	Name	Remark
1	A	white	motor X-axis: phase 2A	
2	B	brown	motor X-axis: phase 1A	
3	C	green	motor X-axis: phase 2B	
4	D	yellow	motor X-axis: phase 1B	
5	E	pink	motor Y-axis: phase 2A	
6	F	grey	motor Y-axis: phase 1A	
7	G	blue	motor Y-axis: phase 2B	
8	H	red	motor Y-axis: phase 1B	
9	I	black	reserved	
10	K	purple	reserved	
11	L	pink - grey	reserved	
12	M	red - blue	foot switch - E1.0	option
13	N	green - white	initiator output X - E1.1	
14	P	green - brown	initiator output Y - E1.2	
15	R	yellow - white	output needle valve - A1.0	
16	S	yellow - brown	+24 V	
17	T	white - grey	+24 V	
18	U	brown - grey	+24 V	
19	V	pink - white	0 V	
20	W	pink - brown	0 V	
21	X	red - white	0 V	
22	Y	-	motor Z-axis: phase 2A	option
23	Z	-	motor Z-axis: phase 1A	option
24	-	-	motor Z-axis: phase 2B	option
25	-	-	motor Z-axis: phase 1B	option
26	-	-	reserved	

Tab. 7

Index

A		H	
Axes.....	3-6	Hand-held unit.....	3-6
B		Homing.....	4-6
Basing point.....	4-6	HPGL.....	4-8
Bellows.....	2-4	I	
Built-in unit.....	2-4, 3-6	Import.....	4-24
vertical, lateral installation.....	2-5	Initiator.....	4-29
C		Installation.....	2-2
Circular text.....	4-8	Software.....	2-3
Alignment.....	4-8	Interference suppression.....	2-6
Combination unit.....	3-6	L	
Communication.....	3-11	Language.....	4-32
Connection cable.....	3-4	LED.....	4-4
Control.....	3-4, 3-10	Lubricants.....	5-3
switch off.....	4-7	M	
switch on.....	4-6	Main menu.....	4-6
Coordinate system.....	4-8	Maintenance.....	5-3
Counter.....	4-12, 4-13	Exhaust air silencer.....	5-5
D		Mechanics.....	5-4
Danger overview.....	1-7	Pneumatic maintenance unit.....	5-10
Data import.....	4-24	Pneumatics.....	5-9
Data matrix.....	4-8	Slide.....	5-8
Date and time.....	4-15	Toothed belt.....	5-6
Diagnostic.....	4-26	Manual control.....	4-28
E		Manual operation.....	4-28
Electronic interference.....	2-5	Marking	
F		Marking speed.....	3-6
Font.....	4-35	Preview.....	4-22
default.....	4-35	start.....	4-23
further.....	4-36	Marking head.....	3-4, 3-6
Foot switch.....	3-4	Marking head origin.....	4-30
G		Marking head parameters.....	4-29
Graphic.....	4-8	Marking speed.....	3-6
HPGL.....	4-8	Marking tool.....	3-7, 4-31
		WE 1.....	3-9
		WE 2.....	3-8
		WE 3.....	3-8
		WP 3.....	3-9
		Marking unit.....	3-5
		Mask.....	4-5
		create.....	4-9
		edit.....	4-11
		load, open.....	4-11
		save.....	4-19
		Mode	
		Edit mode.....	4-25
		Service mode.....	4-25
		Work mode.....	4-25

Needle parameters 4-31

O

Object	4-12
Counter	4-13
Date and time	4-15
Shift index	4-17
User input	4-16
Operation	
Basics	4-5
brief instruction	4-7
LED	4-4
Operating devices	4-3
Operational safety	1-3
Options	4-32
Language	4-32
Mode	4-34
PinWare	4-33
Software adjustments	4-33

P

PC connecting cable.....	3-4
PC, external.....	3-4
Personnel.....	1-2, 1-4
Pin list	
BU1	6-5
BU2	6-6
Connection cable for marking head	6-8
Connection marking head	6-2
START	6-7
Power supply	3-4
Preview	4-22
Project	4-5, 4-20
open	4-21
save.....	4-20

S

Set-up	2-2
Shift index	4-17
Software	3-10
install	2-3
Spare parts	1-5
Stepping motor	
Circuit	6-3
Switch off	4-7
Switch on	4-6
System control	
Diagnostic.....	4-26
Manual control.....	4-28
Marking head origin.....	4-30
Marking head parameters	4-29
Needle parameters.....	4-31
Options	4-32

T

Table unit	3-5
Technical data.....	3-2
Control	3-3
Marking unit.....	3-2
Software	3-3
Text field	4-5, 4-8
Alignment	4-8
create	4-9
edit.....	4-11

U

Unit design	3-5
User input.....	4-16

W

Wildcard	4-12
Day	4-12
Month	4-12
Time.....	4-12
Week	4-12
Year.....	4-12

Drawings, parts lists

Chapter 9

EC declaration of conformity

EC conformity declaration



in terms of EC directives

- Machines 98/37/EG
- Electromagnetic compatibility 89/336/EWG
- Low voltage 73/23/EWG

Hereby we declare that the below designated machine corresponds to the fundamental safety and health requirements of the mentioned EC directives machines in its conceiving and design as well as in the execution brought in circulation by us. In the case of a change of the machine not co-ordinated with us this declaration loses its validity.

Plant/Machine

Make: PinMark needle marking system
Type: 3/5 - 4/6 - 5/9 - 8/14 - 15/20 - 15/30
Machine nr:
Year: as of 2006

Manufacturer

ÖSTLING Markiersysteme GmbH
Broßhauser Str. 27
42697 Solingen
Deutschland

The following harmonized standards were us:

- DIN EN 60204-1
- DIN EN 50081-1
- DIN EN 50082-1
- DIN EN 60947
- DIN EN 60439
- DIN EN ISO 12100-1
- DIN EN ISO 12100-2
- DIN EN 62061
- DIN EN 61508
- DIN EN 983

Following national standards, guidelines and specifications were used:

- VDE 0100
- VDE 0105 part 1 + 2
- VDE 0113 part 2 + 3

A technical documentation is completely present.
The manual belonging to the plant/machine is present.

- ☐ in original version and
☒ in the national language of the user: english

Solingen, 12.04.2006

Ort Datum

Rolf Östling, Geschäftsführer

Unterzeichner und Angaben zum Unterzeichner

A handwritten signature in black ink, appearing to be 'R. Östling', written over a horizontal line.

Unterschrift

Request for service

of company



**Markiersysteme für
Produkt und Verpackung**
Östling Markiersysteme GmbH
Broßhauser Straße 27
42697 Solingen
Tel: 0212 / 2696 - 0
Fax: 0212 / 2696 - 199

Billing address:

Location of machine (if different to above):

Gewährleistung ☐
Kulanz ☐
Rechnung ☐
Termin: _____
Monteur: _____
Erledigt: _____
(is completed by ÖSTLING !)

Contact: _____ Department: _____ Date: _____

Phone no.: _____ Fax no.: _____ Order no.: _____

Request for

☐ Installation ☐ Maintenance ☐ Repair ☐ Training ☐ _____

of

machine:

Pinmarker	<input type="checkbox"/>	Type:	_____
Scraper	<input type="checkbox"/>	Machine no.:	_____
Pad printer	<input type="checkbox"/>	Controller no.:	_____
Electrolytic	<input type="checkbox"/>	Year of manufacture:	_____
Ink Mark	<input type="checkbox"/>		
Laser	<input type="checkbox"/>		

Short description of problem


Please enclose the completed and signed maintenance protocols!

Other

Signature and company stamp: _____

Please enclose a map with directions to the location of the equipment. This will help us to solve the problem quickly.

ÖSTLING - worldwide



Switzerland	France
-------------	--------

Téchnopôle Metz 2000
9 rue Claude Chappe
F-57070 Metz
Tel.: +33 - 387 - 768 339
Fax.: +33 - 387 - 768 329

Sweden	USA
--------	-----

931 East Water Street
Chillicothe
Ohio 45601 USA
Tel.: +1 - 740 - 779 99 18
Fax.: +1 - 740 - 779 99 10